

Signed and approved on behalf of: Sony Europe B.V.



Kris De Pauw
Vice President
Weybridge, 2024-03-25

Sony Europe B.V.
Registered Office: The Heights, Brooklands, Weybridge, Surrey, KT13 0XW, United Kingdom
Incorporated in the Netherlands No. 71682147

Wireless Speaker

- Reference Guide
- Guide de référence
- Guía de referencia
- Referenzanleitung
- Referentiegids

<div> <div></div> <div>Licenses</div> </div> <div> <p>This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license.</p> <p>https://rd1.sony.net/help/speaker/s1/23/</p> <div></div> <div></div> </div>
<div> <div></div> <div>Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.</div> </div> <div> <p>Please note that the use of this accessory with an Apple product may affect wireless performance.</p> <ul style="list-style-type: none">This product is protected by certain intellectual property rights of Microsoft Corporation. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft or an authorized Microsoft subsidiary. MPEG Layer-3 audio coding technology and patents licensed from Fraunhofer IIS and Thomson. </div>
<div> <div></div> <div>Disclaimer regarding services offered by third parties</div> </div> <div> <p>Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.</p> </div>
<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>
<div> <div></div> <div>Barcode</div> </div> <div> <p></p> <p>5 0 4 7 0 6 6 2 3 (1)</p> </div>
<div> <div></div> <div>SRS-XV800</div> </div> <div> <div></div> <div>Model: YY7854E</div> </div>

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>English</div> </div> <div> <div></div> <div>Wireless Speaker</div> </div>
<div> <div></div> <div>Model: YY7854E</div> </div> <div> <p>The term "product" in this document refers to the unit or its accessories.</p> <p>Do not expose the unit to naked flame sources (for example, lighted candles).</p> <p>As the power cord is used to disconnect the unit from the mains, connect the unit to an easily accessible AC outlet. Should you notice an abnormality in the unit, disconnect the power cord from the AC outlet immediately.</p> <p>Do not install the product in a confined space, such as a bookcase or built-in cabinet.</p> <p>The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.</p> <p>Notice for customers: the following information is only applicable to products sold in countries/regions applying EU directives and/or UK applying relevant statutory requirements.</p> <p>This product has been manufactured by or on behalf of Sony Corporation.</p> <p>EU and UK importer: Sony Europe B.V.</p> <p>Inquiries to the EU importer or related to product compliance in Europe should be sent to the manufacturer’s authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciiaan 7-D1, 1930 Zaventem, Belgium.</p> <p>Inquiries to the UK importer or related to product compliance in the UK should be sent to the manufacturer’s authorized representative, Sony Europe B.V., The Heights, Brooklands, Weybridge, Surrey KT13 0XW, United Kingdom.</p> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>English</div> </div> <div> <div></div> <div>Wireless Speaker</div> </div>
<div> <div></div> <div>Model: YY7854E</div> </div> <div> <p>The term "product" in this document refers to the unit or its accessories.</p> <p>Do not expose the unit to naked flame sources (for example, lighted candles).</p> <p>As the power cord is used to disconnect the unit from the mains, connect the unit to an easily accessible AC outlet. Should you notice an abnormality in the unit, disconnect the power cord from the AC outlet immediately.</p> <p>Do not install the product in a confined space, such as a bookcase or built-in cabinet.</p> <p>The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.</p> <p>Notice for customers: the following information is only applicable to products sold in countries/regions applying EU directives and/or UK applying relevant statutory requirements.</p> <p>This product has been manufactured by or on behalf of Sony Corporation.</p> <p>EU and UK importer: Sony Europe B.V.</p> <p>Inquiries to the EU importer or related to product compliance in Europe should be sent to the manufacturer’s authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciiaan 7-D1, 1930 Zaventem, Belgium.</p> <p>Inquiries to the UK importer or related to product compliance in the UK should be sent to the manufacturer’s authorized representative, Sony Europe B.V., The Heights, Brooklands, Weybridge, Surrey KT13 0XW, United Kingdom.</p> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>English</div> </div> <div> <div></div> <div>Wireless Speaker</div> </div>
<div> <div></div> <div>Model: YY7854E</div> </div> <div> <p>The term "product" in this document refers to the unit or its accessories.</p> <p>Do not expose the unit to naked flame sources (for example, lighted candles).</p> <p>As the power cord is used to disconnect the unit from the mains, connect the unit to an easily accessible AC outlet. Should you notice an abnormality in the unit, disconnect the power cord from the AC outlet immediately.</p> <p>Do not install the product in a confined space, such as a bookcase or built-in cabinet.</p> <p>The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.</p> <p>Notice for customers: the following information is only applicable to products sold in countries/regions applying EU directives and/or UK applying relevant statutory requirements.</p> <p>This product has been manufactured by or on behalf of Sony Corporation.</p> <p>EU and UK importer: Sony Europe B.V.</p> <p>Inquiries to the EU importer or related to product compliance in Europe should be sent to the manufacturer’s authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciiaan 7-D1, 1930 Zaventem, Belgium.</p> <p>Inquiries to the UK importer or related to product compliance in the UK should be sent to the manufacturer’s authorized representative, Sony Europe B.V., The Heights, Brooklands, Weybridge, Surrey KT13 0XW, United Kingdom.</p> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>
<div> <div></div> <div>Barcode</div> </div> <div> <p></p> <p>5 0 4 7 0 6 6 2 3 (1)</p> </div>
<div> <div></div> <div>SRS-XV800</div> </div> <div> <div></div> <div>Model: YY7854E</div> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>
<div> <div></div> <div>Barcode</div> </div> <div> <p></p> <p>5 0 4 7 0 6 6 2 3 (1)</p> </div>
<div> <div></div> <div>SRS-XV800</div> </div> <div> <div></div> <div>Model: YY7854E</div> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>French</div> </div> <div> <div></div> <div>Écoute sans fil</div> </div>
<div> <div></div> <div>Modèle: YY7854E</div> </div> <div> <p>Le terme « produit » dans ce document désigne l'appareil ou ses accessoires.</p> <p>N'exposez pas l'appareil à des sources de flamme nue (bougies allumées, par exemple).</p> <p>Comme le cordon d'alimentation est utilisé pour débrancher l'appareil du réseau électrique, branchez l'appareil sur une prise secteur facilement accessible. Si vous remarquez une anomalie de l'appareil, débranchez immédiatement le cordon d'alimentation de la prise secteur.</p> <p>N'installez pas le produit dans un espace clos, comme une bibliothèque ou une armoire encastrée.</p> <p>L'appareil n'est pas déconnecté de la source d'alimentation CA (secteur) tant qu'il reste branché à la prise murale, même s'il a été mis hors tension.</p> <p>Avs aux clients : les informations suivantes ne s'appliquent qu'aux produits vendus dans les pays/régions appliquant les directives de l'UE.</p> <p>Ce produit a été fabriqué par ou pour le compte de Sony Corporation.</p> <p>Importateur dans l'UE : Sony Europe B.V.</p> <p>Les questions basées sur la législation européenne pour l'importateur ou relatives à la conformité des produits doivent être adressées au mandataire : Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciiaan 7-D1, 1930 Zaventem, Belgique.</p> <p>Le soussigné, Sony Corporation, déclare que cet équipement est conforme à la Directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante : https://compliance.sony.eu</p> </div>
<div> <div></div> <div>Fabricant des piles/batteries :</div> </div> <div> <p>ICON ENERGY SYSTEM (SHENZHEN) CO., LTD.</p> <p>201, 301, 401, 501 of Plant B and 101, 201, 301, 401, 501, No.4 Guanguang Road, Luhu Community, Guanhu Street, Longhua District, Shenzhen City, Guangdong Province, 518100, P. R. of Chine</p> </div>
<div> <div></div> <div>SONY</div> </div> <div> <p>Fabricant : Sony Corporation, Importateur/mandataire dans l'UE : Sony Europe B.V., Da Vinciiaan 7-D1, 1930 Zaventem, Belgique.</p> <p>La validité du marquage CE est limitée aux seuls pays/régions dans lesquels il est légalement en vigueur, principalement dans les pays/régions de l'EEE (Espace Économique Européen) et en Suisse. La validité du marquage UKA est limitée aux seuls pays/régions dans lesquels il est légalement en vigueur, principalement au Royaume-Uni.</p> </div>
<div> <div></div> <div>Élimination des piles et accumulateurs et des équipements électriques et électroniques usagés (applicable dans les pays de l'Union Européenne et dans les autres pays disposant de systèmes de collecte sélective)</div> </div> <div> <p>Ce symbole apposé sur le produit, la pile ou l'accumulateur, ou sur l'emballage, indique que le produit et les piles et accumulateurs fournis avec ce produit ne doivent pas être traités comme de simples déchets ménagers. Sur certains types de piles, ce symbole apparaît parfois combiné avec un symbole chimique. Le symbole pour le plomb (Pb) est rajouté lorsque ces piles contiennent plus de 0,004% de plomb. En vous assurant que les produits, piles et accumulateurs sont mis au rebut de façon appropriée, vous participez activement à la prévention des conséquences négatives que leur mauvais traitement pourrait provoquer sur l'environnement et sur la santé humaine. Le recyclage des matériaux contribue par ailleurs à la préservation des ressources naturelles. Pour les produits qui, pour des raisons de sécurité ou d'intégrité des données, nécessitent une connexion permanente à une pile ou à un accumulateur intégré(e), il conviendrait de vous rapprocher d'un service technique qualifié pour effectuer son remplacement. En rapportant votre appareil électrique, les piles et accumulateurs en fin de vie à un point de collecte approprié, vous vous assurez que le produit, la pile ou l'accumulateur intégré sera traité correctement. Pour tous les autres cas de figure et afin d'enlever les piles ou accumulateurs en toute sécurité de votre appareil, reportez-vous au manuel d'utilisation. Rappelez les piles et accumulateurs, et les équipements électriques et électroniques usagés au point de collecte approprié pour le recyclage. Pour toute information complémentaire au sujet du recyclage de ce produit ou des piles et accumulateurs, vous pouvez contacter votre municipalité, votre déchèterie locale ou le point de vente où vous avez acheté ce produit.</p> </div>
<div> <div></div> <div>N'exposez pas les piles (bloc-batterie ou piles installées) à une chaleur excessive, telle que le soleil, un feu ou autre, pendant une longue période.</div> </div> <div> <p>Ne soumettez pas les batteries à des conditions de température extrêmement basses qui pourraient entraîner une surchauffe et un emballement thermique.</p> <p>Ne démontez pas, n'ouvrez pas et ne défilutsez pas les batteries rechargeables.</p> <p>En cas de fuite de la batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si un contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.</p> <p>Les batteries rechargeables doivent être chargées avant d'être utilisées. Reportez-vous toujours aux instructions du fabricant ou au manuel du produit pour obtenir des instructions de chargement pertinentes.</p> <p>Après de longues périodes de stockage, il peut être nécessaire de charger et de décharger les batteries rechargeables plusieurs fois pour obtenir une performance maximale.</p> <p>Mettez au rebut correctement.</p> </div>
<div> <div></div> <div>Ce produit comporte un ou des aimants qui peuvent perturber les stimulateurs cardiaques, les valves de dérivation programmables et d'autres dispositifs médicaux.</div> </div> <div> <p>Ne placez pas ce produit près de personnes utilisant ce type d'appareil médical. Consultez votre médecin avant d'utiliser ce produit si vous utilisez ce type d'appareil médical.</p> </div>
<div> <div></div> <div>Cet appareil a été testé et déclaré conforme aux limites de la norme EMC en utilisant un câble de connexion de moins de 3 m.</div> </div> <div> <p>L'insertion de la fiche USB ou de la fiche CA alors qu'elle est humidie peut provoquer un court-circuit à cause de la présence de gouttes d'eau ou de liquide (eau du robinet, eau de mer, soda, etc.) sur l'appareil principal ou le câble de charge.</p> <p>Ceci peut provoquer des dysfonctionnements ou une surchauffe anormale.</p> <p>N'insérez jamais la fiche USB ou la fiche CA alors que l'appareil principal ou le câble de charge est humidifié.</p> </div>
<div> <div></div> <div>Cet appareil doit être installé et utilisé en gardant une distance d'au moins 20 cm ou plus entre l'élément rayonnant et le corps humain.</div> </div> <div> <p>Notez que les roulettes peuvent ne pas pivoter correctement si du sable ou de la poussière adhère à l'axe de la roulette, ou si de l'herbe ou d'autres débris s'enroulent autour de l'axe.</p> </div>

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>
<div> <div></div> <div>Barcode</div> </div> <div> <p></p> <p>5 0 4 7 0 6 6 2 3 (1)</p> </div>
<div> <div></div> <div>SRS-XV800</div> </div> <div> <div></div> <div>Model: YY7854E</div> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>
<div> <div></div> <div>Barcode</div> </div> <div> <p></p> <p>5 0 4 7 0 6 6 2 3 (1)</p> </div>
<div> <div></div> <div>SRS-XV800</div> </div> <div> <div></div> <div>Model: YY7854E</div> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>
<div> <div></div> <div>Barcode</div> </div> <div> <p></p> <p>5 0 4 7 0 6 6 2 3 (1)</p> </div>
<div> <div></div> <div>SRS-XV800</div> </div> <div> <div></div> <div>Model: YY7854E</div> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

<div> <div></div> <div>Notes on water resistant feature (Read before using the unit)</div> </div> <div> <p>The supplied accessories are not water resistant.</p> </div>
<div> <div></div> <div>On water resistant performance of the unit</div> </div> <div> <p>With the cap securely closed, this unit has a drip-proof performance equivalent to IPX4 (when placed vertically)/IPX2 (when placed horizontally), which are "protection against ingress of water" ratings defined by IEC 60529 "Degrees of protection provided by enclosures (IP Code)" for electrical equipment. The supplied accessories and the connectors of this unit (AC IN/USB/AUDIO IN/OPTICAL IN/MIC/GUITAR) are neither water resistant nor dustproof. To reduce the risk of fires or electric shocks, do not expose the unit to water or droplets while using any connectors (AC IN/USB/AUDIO IN/OPTICAL IN/ MIC/GUITAR).</p> </div>
<div> <div></div> <div>Note</div> </div> <div> <p>That malfunctions as a result of water immersion or dust intrusion caused by misuse by the customer are not covered by the warranty.</p> </div>
<div> <div></div> <div>Barcode</div> </div> <div> <p></p> <p>5 0 4 7 0 6 6 2 3 (1)</p> </div>
<div> <div></div> <div>SRS-XV800</div> </div> <div> <div></div> <div>Model: YY7854E</div> </div>

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

Cautionfully note the precautions below to ensure proper use of the unit.

- This unit does not have a design that is resistant to water damage. Do not put the unit in the water or directly under the water gushing out of the faucet to avoid a malfunction.
- Do not pour high-temperature water or blow hot air from a hair dryer or any other appliance on the unit directly. Also never use the unit in a place subject to high temperatures, such as in a sauna or near a heat source.

